



FLOOR MUFFLER® LVT ULTRASEAL

The adhesives below have been tested and approved by the respective manufacturer for installation of floorMuffler underlayments. Diversified Industries has not independently verified this information. Contact the adhesive manufacturer directly to obtain their installation instructions and warranty information prior to use.

FOR ADHERING THE FLOORMUFFLER TO THE LUXURY VINYL FLOOR.

DRITAC		MAPEI	
5900 MegaBond	UltraBond Eco 350		
5700 Strong Bond	UltraBond Eco 360		
6200 PSA	UltraBond Eco 373		
5500 PowerBond			
TAYLOR		STAUF USA	
Pinnacle	UVF-867		
Dynamic	AEM-852		
Resolute	PSA-832		
Bruce BondLink	D737		
Bruce TuffLink	LVP-777		
NORTH AMERICAN		FRANKLIN	
Ever Bond PSA Super	TiteBond 670		
Ever Bond PSA Plus	TiteBond 780		
BOSTIK		XL BRANDS	
LVT-Lock+	Stix 2230*		

FOR ADHERING THE UNDERLAYMENT TO A WOOD OR CONCRETE SUBFLOOR

BOSTIK		MAPEI			
GreenForce	UltraBond Eco 811				
Bostik's Best	UltraBond Eco 350				
Pro-MSP	UltraBond Eco 360				
Pro-Cure	UltraBond Eco 373				
EFA+					
TAYLOR					
2071	Timberline	Equalizer Pro			
Pinnacle	Aspen	Preconnect Plus			
Dynamic	Ironwood	Ridgeline			
Resolute	Summit Select				
DRITAC		STAUF USA			
7800 Supreme Green	BCS-827				
FRANKLIN		N. AMERICAN		XL BRANDS	
TiteBond 670	Ever Bond PSA Super	Stix 2230*			
TiteBond 801	Ever Bond PSA Plus				