



FLOOR MUFFLER® ULTRASEAL

The adhesives below have been tested and approved by the respective manufacturer for installation of floorMuffler underlayments. Diversified Industries has not independently verified this information. Contact the adhesive manufacturer directly to obtain their installation instructions and warranty information prior to use.

FOR ADHERING THE FLOORMUFFLER TO THE WOOD FLOORING

DRITAC	BOSTIK
7700 Easy Clean 4n1	GreenForce
7400 Easy Spread	Bostik's Best
7300 Sure Bond	Pro-MSP
7800 Supreme Green	Pro-Cure
	EFA+

MAPEI	STAUF USA
UltraBond Eco 962	AEM-852
UltraBond Eco 373	

FRANKLIN	NORTH AMERICAN
Titebond 801	Ever Bond PSA Super
Titebond 811	
Titebond 821 - Step	
Titebond 771 - Step	

TAYLOR
2071

FOR ADHERING THE UNDERLAYMENT TO A WOOD OR CONCRETE SUBFLOOR

BOSTIK	MAPEI
GreenForce	UltraBond Eco 811
Bostik's Best	UltraBond Eco 350
Pro-MSP	UltraBond Eco 360
Pro-Cure	UltraBond Eco 373
EFA+	

TAYLOR		
2071	Timberline	Equalizer Pro
Pinnacle	Aspen	Preconnect Plus
Dynamic	Ironwood	Ridgeline
Resolute	Summit Select	

DRITAC	STAUF USA
7800 Supreme Green	BCS-827

FRANKLIN	N. AMERICAN	XL BRANDS
TiteBond 670	Ever Bond PSA Super	Stix 2230*
TiteBond 801	Ever Bond PSA Plus	