



## FLOORMUFFLER® ULTRASEAL

The adhesives below have been tested and approved by the respective manufacturer for installation of floorMuffler® underlayments. Diversified Industries has not independently verified this information. Contact the adhesive manufacturer directly to obtain their installation instructions and warranty information prior to use.

### For adhering flooring to the floorMuffler ultraSeal

DRITAC	BOSTIK	TAYLOR	FRANKLIN / TITEBOND
7300 Sure Bond	GreenForce	2071	Titebond 801
7400 Easy Spread	Bostik's Best	-	Titebond 811
7700 Easy Clean 4n1	Pro-MSP	-	Titebond 771 - Step
7800 Supreme Green	Pro-Cure	-	Titebond 821 - Step
-	EFA+	-	-

  

MAPEI	STAUF USA	NORTH AMERICAN
UltraBond Eco 373	AEM-852	Ever Bond PSA Super
UltraBond Eco 962	-	-

### For adhering the floorMuffler ultraSeal to wood or concrete subfloor

DRITAC	BOSTIK	TAYLOR	FRANKLIN / TITEBOND	
7800 Supreme Green	GreenForce	2071	Ironwood	TiteBond 670
-	Bostik's Best	Pinnacle	Summit Select	TiteBond 801
-	Pro-MSP	Dynamic	Equalizer Pro	-
-	Pro-Cure	Resolute	Preconnect Plus	-
-	EFA+	Timberline	Ridgeline	-
-	-	Aspen	-	-

  

MAPEI	STAUF USA	NORTH AMERICAN	XL BRANDS
UltraBond Eco 350	BCS-827	Ever Bond PSA Super	Stix 2230*
UltraBond Eco 360	-	Ever Bond PSA Plus	-
UltraBond Eco 373	-	-	-
UltraBond Eco 811	-	-	-