



FLOORMUFFLER® ULTRASEAL

The adhesives below have been tested and approved by the respective manufacturer for installation of floorMuffler® underlayments. Diversified Industries has not independently verified this information. Contact the adhesive manufacturer directly to obtain their installation instructions and warranty information prior to use.

FOR ADHERING THE FLOORMUFFLER TO LUXURY VINYL FLOORS

DRITAC	BOSTIK	TAYLOR	FRANKLIN / TITEBOND
7300 Sure Bond	GreenForce	2071	Titebond 801
7400 Easy Spread	Bostik's Best	-	Titebond 811
7700 Easy Clean 4n1	Pro-MSP	-	Titebond 771 - Step
7800 Supreme Green	Pro-Cure	-	Titebond 821 - Step
-	EFA+	-	-

MAPEI	STAUF USA	NORTH AMERICAN
UltraBond Eco 373	AEM-852	Ever Bond PSA Super
UltraBond Eco 962	-	-

FOR ADHERING THE FLOORMUFFLER TO WOOD OR CONCRETE SUBFLOOR

DRITAC		BOSTIK		TAYLOR		FRANKLIN / TITEBOND			
7800 Supreme Green		GreenForce		2071		Ironwood		TiteBond 670	
-		Bostik's Best		Pinnacle		Summit Select		TiteBond 801	
-		Pro-MSP		Dynamic		Equalizer Pro		-	
-		Pro-Cure		Resolute		Preconnect Plus		-	
-		EFA+		Timberline		Ridgeline		-	
-		-		Aspen		-		-	
MAPEI		STAUF USA		NORTH AMERICAN		XL BRANDS			
UltraBond Eco 350		BCS-827		Ever Bond PSA Super		Stix 2230*			
UltraBond Eco 360		-		Ever Bond PSA Plus		-			
UltraBond Eco 373		-		-		-			
UltraBond Eco 811		-		-		-			