

The adhesives below have been tested and approved by the respective manufacturers for installation of the floorMuffler® underlayments. Diversified Industries has not independently verified this information. Contact the adhesive manufacturer directly to obtain their installation instructions and warranty information prior to use.

Manufacturer	ADHESIVE: <i>Underlayment to Substrate</i>	ADHESIVE: <i>Engineered Wood to Underlayment</i>	ADHESIVE: <i>LVT Tile/Plank to Underlayment</i>	TROWEL SIZE
DriTac Adhesives: p: 800-394-9310; w - www.dritac.com				
DriTac	7800 Supreme Green	7700 Easy Clean 4n1	5900 MegaBond	*
DriTac	-	7400 Easy Spread	5700 StrongBond	*
DriTac	-	7300 SureBond	6200 PSA	*
DriTac	-	7800 Supreme Green	5500 PowerBond	*
Taylor Adhesives: p: 800-868-GLUE; w: www.wftaylor.com				
Taylor Adhesives	2071	2071	Pinnacle	*
Taylor Adhesives	Pinnacle	-	Dynamic	*
Taylor Adhesives	Dynamic	-	Resolute	*
Taylor Adhesives	Resolute	-	-	*
Mapei Adhesives: p: 800-992-6273; w: www.mapei.com/us				
Mapei	UltraBond Eco 811	UltraBond Eco 962	UltraBond Eco 350	*
Mapei	UltraBond Eco 350	UltraBond Eco 373	UltraBond Eco 360	*
Mapei	UltraBond Eco 360	-	UltraBond Eco 373	*
Mapei	UltraBond Eco 373	-	-	*
North American Adhesives: p: 800-747-2722 ; w: www.na-adhesives.com				
NAA Adhesive	Ever Bond PSA Plus	Ever Bond PSA Super	Ever Bond PSA Plus	*
NAA Adhesive	Ever Bond PSA Super	-	Ever Bond PSA Super	*
Titebond: p: 800-669-4583; w: www.titebond.com				
Franklin Adhesives	Titebond 670	Titebond 801	Titebond 670	*
Franklin Adhesives	Titebond 801	Titebond 811	Titebond 780	*
Franklin Adhesives	-	Titebond 821 - Step	-	*
Franklin Adhesives	-	Titebond 771- Step	-	*
Bostik Adhesives: p: 800-7-BOSTIK; w: www.bostik-us.com				
Bostik Adhesives	GreenForce	GreenForce	LVT-Lock+	*
Bostik Adhesives	Bostik's BEST	Bostik's BEST	-	*
Bostik Adhesives	Pro-MSP	Pro-MSP	-	*
Bostik Adhesives	Pro-Cure	Pro-Cure	-	*
Bostik Adhesives	EFA+	EFA+	-	*
XL Brands: p: 706-272-5807; w: www.xlbrands.com				
XL Brands	Stix 2230	-	Stix 2230	*
STAUF USA: p: 866-GLUE USA; w: http:www.staufusa.com				
STAUF	BCS-827	AEM-852	UVF-867	*
STAUF	-	-	AEM-852	*
STAUF	-	-	PSA-832	*
STAUF	-	-	D737	*
STAUF	-	-	LVP-777	*

***ALWAYS speak to respective adhesive manufacturer directly for proper trowel recommendations.**