



FLOOR MUFFLER® ULTRASEAL

QUIETCURE™ ULTRASEAL
by FLOOR MUFFLER

The adhesives below have been tested and approved by the respective manufacturer for installation of floorMuffler underlayments. Diversified Industries has not independently verified this information. Contact the adhesive manufacturer directly to obtain their installation instructions and warranty information prior to use.

FOR ADHERING THE FLOORMUFFLER TO THE WOOD FLOORING

DRITAC		BOSTIK	
7700 Easy Clean 4n1	GreenForce	Pro-Cure	
7400 Easy Spread	Bostik's Best	EFA+	
7300 Sure Bond	Pro-MSP		
7800 Supreme Green			
MAPEI		STAUF USA	
UltraBond Eco 962	AEM-852		
UltraBond Eco 373			
FRANKLIN		NORTH AMERICAN	
Titebond 821 - Step	Ever Bond PSA Super		
Titebond 771 - Step			
TAYLOR			
2071	Ironwood	Equalizer Pro	
Timberline	Summit Select	Ridgeline	
Aspen	Proconnect Plus		

FOR ADHERING THE UNDERLAYMENT TO A WOOD OR CONCRETE SUBFLOOR

BOSTIK		MAPEI			
GreenForce	UltraBond Eco 811				
Bostik's Best	UltraBond Eco 350				
Pro-MSP	UltraBond Eco 360				
Pro-Cure	UltraBond Eco 373				
EFA+					
TAYLOR					
2071	Timberline	Equalizer Pro			
Pinnacle	Aspen	Preconnect Plus			
Dynamic	Ironwood	Ridgeline			
Resolute	Summit Select				
DRITAC		STAUF USA			
7800 Supreme Green	BCS-827				
FRANKLIN		N. AMERICAN		XL BRANDS	
TiteBond 670	Ever Bond PSA Super	Stix 2230*			
TiteBond 801	Ever Bond PSA Plus				