



FLOORMUFFLER® & QUIETCURE™ ULTRASEAL

The adhesives below have been tested and approved by the respective manufacturer for installation of floorMuffler® underlayments. Diversified Industries has not independently verified this information. Contact the adhesive manufacturer directly to obtain their installation instructions and warranty information prior to use.

FOR ADHERING THE FLOORMUFFLER TO WOOD FLOORS

DRITAC	BOSTIK	TAYLOR	FRANKLIN / TITEBOND	
7300 Sure Bond	GreenForce	2071	Proconnect Plus	Titebond 741
7400 Easy Spread	Bostik's Best	Timberline	Equalizer Pro	Titebond 801
7700 Easy Clean 4n1	Pro-MSP	Aspen	Ridgeline	Titebond 811
7800 Supreme Green	Pro-Cure	Ironwood	-	Titebond 771 - Step
-	EFA+	Summit Select	-	Titebond 821 - Step

MAPEI	STAUF USA	NORTH AMERICAN		
UltraBond Eco 373	AEM-852	Ever Bond PSA Super		
UltraBond Eco 962	-	-		

FOR ADHERING THE FLOORMUFFLER TO WOOD OR CONCRETE SUBFLOOR

DRITAC	BOSTIK	TAYLOR	FRANKLIN / TITEBOND	
7800 Supreme Green	GreenForce	2071	Ironwood	TiteBond 741
-	Bostik's Best	Pinnacle	Summit Select	TiteBond 801
-	Pro-MSP	Dynamic	Equalizer Pro	TiteBond 811
-	Pro-Cure	Resolute	Preconnect Plus	TiteBond 771 - Step
-	EFA+	Timberline	Ridgeline	TiteBond 821 - Step
-	-	Aspen	-	-

MAPEI	STAUF USA	NORTH AMERICAN	XL BRANDS
UltraBond Eco 350	BCS-827	Ever Bond PSA Super	Stix 2230*
UltraBond Eco 360	-	Ever Bond PSA Plus	-
UltraBond Eco 373	-	-	-
UltraBond Eco 811	-	-	-