

APPROVED ADHESIVES



FLOOR MUFFLER® ULTRASEAL

QUIETCURE™ ULTRASEAL by FLOOR MUFFLER

The adhesives below have been tested and approved by the respective manufacturer for installation of floorMuffler underlayments. Diversified Industries has not independently verified this information. Contact the adhesive manufacturer directly to obtain their installation instructions and warranty information prior to use.

FOR ADHERING THE FLOORMUFFLER TO THE WOOD FLOORING

DRITAC		BOSTIK	
7700 Easy Clean 4n1		GreenForce	Pro-Cure
7400 Easy Spread		Bostik's Best	EFA+
7300 Sure Bond		Pro-MSP	
7800 Supreme Green			
MAPEI		STAUF USA	
UltraBond Eco 962		AEM-852	
UltraBond Eco 373			
FRANKLIN		NORTH AMERICAN	
Titebond 801		Ever Bond PSA Super	
Titebond 811			
Titebond 821 - Step			
Titebond 771 - Step			
TAYLOR			
2071	Ironwood	Equalizer Pro	
Timberline	Summit Select	Ridgeline	
Aspen	Proconnect Plus		

FOR ADHERING THE UNDERLAYMENT TO A WOOD OR CONCRETE SUBFLOOR

BOSTIK		MAPEI
GreenForce		UltraBond Eco 811
Bostik's Best		UltraBond Eco 350
Pro-MSP		UltraBond Eco 360
Pro-Cure		UltraBond Eco 373
EFA+		
TAYLOR		
2071	Timberline	Equalizer Pro
Pinnacle	Aspen	Preconnect Plus
Dynamic	Ironwood	Ridgeline
Resolute	Summit Select	
DRITAC	STAUF USA	
7800 Supreme Green	BCS-827	
FRANKLIN	N. AMERICAN	XL BRANDS
TiteBond 670	Ever Bond PSA Super	Stix 2230*
TiteBond 801	Ever Bond PSA Plus	