






<p>1</p> 	<p>1. Make sure the subfloor is structurally sound, level and is free of dust and debris.</p> <p>2. Check for protruding nails and/or defects in the subfloor. If installing over concrete, the concrete must be dry with moisture emission rates that do not exceed 3 lbs. per 1000 square feet per 24 hours as measured by the Anhydrous Calcium Chloride Test.</p>
<p>2</p> 	<p>1. Start in a corner and begin installing the Natura™ parallel to the wall in the opposite direction that you plan to install the flooring planks.</p> <p>2. When installing the Natura™, leave at least 2" going up the wall.</p>
<p>3</p> 	<p>1. Roll out the next roll of Natura™ in the same manner, making sure that the foam seams are butted together.</p>
<p>4</p> 	<p>1. If installing Natura™ on concrete or below grade subfloors, be sure to tape the seams together with 2" tape that meets the moisture vapor transmission rate for this type of installation.</p>
<p>5</p> 	<p>1. Install the flooring per manufacturer's instructions.</p>