






<p>1</p> 	<ol style="list-style-type: none"> 1. Make sure the subfloor is structurally sound, level and is free of dust and debris. 2. Check for protruding nails and/or defects in the subfloor. If installing over concrete, the concrete must meet the floor covering manufacturer's acceptable moisture tolerance range.
<p>2</p> 	<ol style="list-style-type: none"> 1. Start in a corner with the tape strip side next to the wall and the overlapping film towards the open room. 2. Install floorMuffler® LVT ultraSeal (overlap film side down) parallel to the wall in the opposite direction that you plan to install the flooring planks. 3. When installing the floorMuffler® LVT ultraSeal, leave at least 2" going up the wall (you will trim this part after installing the floor).
<p>3</p> 	<ol style="list-style-type: none"> 1. Be sure to unfold the overlap plastic film, extending it 3" from the foam. 2. Roll out the next roll of floorMuffler® LVT ultraSeal in the same manner, making sure that the foam seams are butted together. 3. Be sure to overlap only the moisture barrier plastic film and not the underlayment pad.
<p>4</p> 	<ol style="list-style-type: none"> 1. Remove the adhesive liner and adhere the underlayment to the plastic film overlap.
<p>5</p> 	<ol style="list-style-type: none"> 1. Install the flooring per manufacturer's instructions.