






<p>1</p> 	<p>1. Make sure the subfloor is structurally sound, level and is free of dust and debris.</p> <p>3. Check for protruding nails and/or defects in the subfloor. If installing over concrete, the concrete must be dry with moisture emission rates that do not exceed 3 lbs. per 1000 square feet per 24 hours as measured by the Anhydrous Calcium Chloride Test.</p>
<p>2</p> 	<p>1. Start in a corner with the tape strip side next to the wall and the overlapping film toward the open room.</p> <p>2. Install floorMuffler® LVT UltraSeal (film side down) parallel to the wall in the opposite direction that you plan to install the flooring planks.</p> <p>3. When installing the floorMuffler® LVT UltraSeal, leave at least 2" going up the wall.</p>
<p>3</p> 	<p>1. Be sure to unfold the film, extending it 3" from the foam.</p> <p>2. Roll out the next roll of floorMuffler® LVT UltraSeal in the same manner, making sure that the foam seams are butted together.</p> <p>3. Be sure to overlap only the moisture barrier lip and not the foam pad.</p>
<p>4</p> 	<p>1. Remove the adhesive liner and adhere the foam to the film overlap.</p>
<p>5</p> 	<p>1. Install the flooring per manufacturer's instructions.</p>